

**AVK**

Description and adjusting instructions  
Additional module "CUN1"  
Voltage regulator "COSIMAT N"



## General

"CUN1" module is an additional component for the "COSIMAT N" voltage regulator. "CUN1" and "COSIMAT N" are interconnected by a screened 4 pole signal wire.

The synchronizing procedure of a AC alternator with the mains, equal frequencies and phase position as well as voltage balance are essential to prevent high reactive currents at the instant of synchronization.

Using module "CUN1" balancing of the alternator voltage can be automated.

The mains voltage is measured and the rated value of the alternator voltage will be adjusted automatically to match the mains voltage by "CUN1".

The voltage balance must be released by a potential free contact and this is indicated at the "CUN1" by a LED.

After synchronization of the alternator, the release is switched again.

### Utilization with power factor regulator:

The external voltage setting potentiometer of the "COSIMAT N" voltage regulator is set to rated voltage when the alternator is running without load.

When in parallel operation with the mains, the power factor regulator controls the alternator excitation.

When a power factor regulator is used, the external voltage setting potentiometer of the "COSIMAT N" voltage regulator must not be re-adjusted during parallel operation.

### Utilization without power factor regulator:

The external voltage setting potentiometer of the "COSIMAT N" voltage regulator is set to rated voltage when the alternator is running without load.

After release, the "CUN1" adjusts the alternator voltage to the mains voltage.

After synchronization, the adjustment of the external voltage setting potentiometer of "COSIMAT N" determines the alternator reactive current.

## 2. Connecting, adjusting and indicating elements

US 500  
US 250  
US 0

Connection of the mains voltage in two ranges:

US 500  $\Leftrightarrow$  US 0 = 250 VAC up to 500 VAC  
US 250  $\Leftrightarrow$  US 0 = 90 VAC up to 250 VAC

By adjusting once with the two trimmers "Coarse" and "Fine", the alternator voltage is adjusted to the mains voltage.

13  
14

The "CUN1" function is released by a potential free NO contact (switching capacity 24 VDC / 20 mADC).

220V  
80V  
0V

Supply of the "CUN1" in two ranges:

220V  $\Leftrightarrow$  0V = 220 VAC  $\pm$  20 %  
80V  $\Leftrightarrow$  0V = 80 VAC  $\pm$  20 %

At the 80 V connection the "CUN1" can be directly supplied from the aux. excitation voltage (see connection diagram).

Consumption is 2 VA.

t  
s  
n  
-

These are the control connectors to the "COSIMAT N" voltage regulator.

Via a 4 pole screened wire the "CUN1" must be interconnected with the "COSIMAT N" voltage regulator (see connection diagram). At the same time connection "\*" at the "CUN1" is used as screen potential.

This control line must not be longer than 2 m.

## Coarse

Adjusting potentiometer for coarse adjustment of the alternator voltage to the mains voltage.

Direction of force:

- ☞ Left stop = minimum alternator voltage position
- ☜ Right stop = maximum alternator voltage position

## Fine

Adjusting potentiometer for fine adjustment of the alternator voltage to the mains voltage.

Direction of force:

- ☞ Left stop = minimum alternator voltage position
- ☜ Right stop = maximum alternator voltage position

## Sollwert / Set value

This potentiometer may be used instead of the external "COSIMAT N" setting rheostat. Slick the coding plug on the side near this potentiometer. If an external "COSIMAT N" rheostat shall be used, delete the a/m coding plug.

## DTE

When using the P.F. regulator "COS" in connection with "CUN1", the alternator is operated mainly in parallel, the external "COSIMAT N" setting rheostat may be deleted, as during parallel operation the excitation is automatically controlled by the P.F. regulator.

The resistance of the external "COSIMAT N" setting rheostat must remain for functional reasons, the internal "CUN1" potentiometer "Set value" must be activated

Direction of action:

- ☞ Left stop position = Minimum alternator voltage
- ☜ Right stop position = Maximum alternator voltage.

## Active

LED indication

The LED lights up when the "CUN1" is released.

## 3. Setting into operation

Basic adjustment at the "CUN1":

- ① Poti "Grob/Coarse" = in left stop position
- ② Poti "Fein/Fine" = turn 10 to 15 times to the right from left stop position
- ③ Potentiometer "Sollwert/Set value" (mode of use see 2. connection, adjusting and monitoring device) in centre position.
- ④ Do not release "CUN1"


Basic adjustment at the "COSIMAT N":

- ① External voltage setting potentiometer in mid-position
- ② R4 in left stop position

Setting into operation:

- ① Start the alternator and adjust alternator rated voltage by turning R4 (at the "COSIMAT N") to the right.
- ② Release "CUN1" (LED Active is alight). The alternator voltage drops.
- ③ Adjust the alternator voltage coarse to the mains voltage by turning poti "Grob/Coarse" (at the "CUN1") to the right.
- ④ Thereafter fine adjustment with poti "Fein/Fine" (at the "CUN1").

FIG. 1 - Connection diagram



CUN-1

Switch in 3 phase  
Stellung multi  
in this position  
and value is correct